

# Omnino 4



**Contents**

- 1 Base Unit
- 2 Monitor

**Included fittings** Your Omnino 4 has been shipped with a multi-purpose screw pack. You will not need to use all the screws in the pack to complete this assembly. You will require the screws shown below:



Screw A  
( x 1 )



Screw B  
( x 2 )



Screw C  
( x 3 )

**Included cables**  
Depending on your configuration you will receive one split power cable for the base unit and monitor and one or more of the following cables: video, audio.

**Tools required**  
Cross-head (philips-head) screwdriver  
Optional security screwdriver (order EMSECDRV from Viglen)

### Step 1 Remove the Back Cover

- Slide the locking latch to release the back cover
- Slide the back cover up, then pull it away from the base unit.



### Step 2 Attach the Monitor

**1** **WARNING:** Compressed Spring  
Apply firm pressure to the top of the monitor bracket before removing the shipping pin.




**1** **CAUTION!** Take care when removing the monitor stand shipping pin.  
The monitor stand contains a strong spring under pressure. Apply firm pressure to the top of the monitor bracket before pulling the pin out.  
**Optional:** Fit 1x Screw C in the shipping pin hole to restrict downward movement of large monitors.

**2** Fix 2x Screw B (lug screw) to the lower VESA mounting holes in the rear of the monitor. Refer to your monitor manual for instructions on how to remove the monitor's stand.

**3** Unlock the cable window in the base unit and feed the monitor signal and power cables through. Place the monitor face down in front of the base unit and connect the monitor cables.

**4** Lift the monitor onto the monitor stand VESA bracket and hang the monitor by engaging the lug screws in the lower holes

**5** Hold the monitor in place and secure it using 2x Screw C.



### Step 3 Connect Cables

- Remove the side panel of the cable bay by sliding it backwards and lifting it away.
- Connect the monitor signal cable, mouse, keyboard and other accessories.
- Secure the mouse, keyboard, power and other external cables using the cable strap at the bottom of the cable bay.
- Replace the side panel of the cable bay.



### Step 4 Replace the Back Cover

- Replace the back cover by applying it flat to the back of the base unit, engaging its lugs and pushing firmly downwards. Care should be taken to ensure that all cables are routed through the cable window in the bottom of the cover.
- Optional:** Fit 1x Security Screw A into the locking clip to deter unauthorised opening.
- Optional:** Fit a Kensington-style locking cable or clip to lock the cover and secure the Omnino 4 to the desktop.



## Viglen System Recovery Utility (Optional)

Under certain conditions you may need to reset the software originally installed on your computer to factory conditions, this can be put down to many different reasons:

- Accidental deletion of system files.
- Incompatible software has been installed.
- Incompatible changes to the system settings.

At Viglen, we understand that unless you have professional knowledge of computer systems, reinstallation can be a costly and time-consuming affair, especially for new users. This is why we have created the Viglen System Recovery Utility (VSRU) – designed to automatically reinstall your computer software quickly and efficiently.

Before proceeding with system recovery, please observe the following recommended guidelines.

- Back up all personal files to a CD or a suitable backup device before proceeding with the recovery procedure.
- Any subsequent software installed by the user must therefore be manually reinstalled – Please refer to the manuals that came with your software for installation instructions.
- Once initiated, all data stored on the system will be destroyed and will therefore not be recoverable.

### Using the Recovery Utility

Please read the recommended guidelines above before continuing with the recovery procedures:

1. Shutdown your Viglen PC (if applicable) and switch off.
2. Insert the Viglen Recovery Utility CD into the CD-ROM drive.
3. Switch your computer back on.
4. The Viglen Recovery Utility CD will now load.
5. When prompted, please type 'factory' and press the 'Enter' key to initiate system recovery.
6. A Windows style screen will now appear with two horizontal bars showing the status of the recovery sequence. Please wait while the procedure completes.
7. When prompted, remove the Recovery Utility CD from the drive and press a key to restart the computer. Windows will now start up and you will be prompted to enter your User Information – Please refer to the Software Guide supplied with your Viglen PC.

### Your Viglen Recovery Utility CD....

#### WARNING

ONLY TO BE USED IF YOUR VIGLEN PC HAS BECOME UNSTABLE OR YOU HAVE BEEN ADVISED OTHERWISE BY A MEMBER OF VIGLEN TECHNICAL SUPPORT. ALL PERSONAL DOCUMENTS WILL BE LOST IF THIS CD IS ACTIVATED.

Hopefully, you should never need to use this utility, but in the unfortunate event that your system must be reinstalled, please keep this Getting Started Guide and the Viglen Recovery Utility CD in a safe place to help ensure a hassle-free recovery.

## Getting Help at Viglen

### Technical Support

If you have any queries concerning the following:

1. Hardware configuration problems.
2. You wish to return your hardware for repair or arrange a service visit (subject to contract).
3. You have installation or set up difficulties.
4. You require additional drivers.

Please call our TECHNICAL SUPPORT department on **01727 201 850**

### Customer Care

If you have any queries concerning the following:

1. Parts missing or damaged from your Viglen PC order.
2. Incorrect goods supplied against your Viglen PC order.
3. Any complaint with a courier or delivery in general.
4. Collection of any computers or parts.
5. You have ordered or wish to order spare parts.
6. You wish to return your Viglen PC for an upgrade.
7. You wish to know the status of any returned Viglen PC.
8. You require information on upgrading new or old systems.

Please call our CUSTOMER CARE department on **01727 201 810**



**Viglen Limited,**  
VHQ,  
7 Handley Page Way,  
Old Parkbury Lane,  
Colney Street,  
St. Albans, Hertfordshire  
AL2 2DQ

Corporate Sales **01727 201 830**  
Education Sales **01727 201 860**  
Public Sector Sales **01727 201 830**  
Schools Sales **01727 201 820**

Email [sales@viglen.co.uk](mailto:sales@viglen.co.uk)  
Web [www.viglen.co.uk](http://www.viglen.co.uk)

## Important

**Please read this pamphlet before switching on the Viglen PC and store in a safe place. For further information regarding your Viglen PC please refer to the Viglen Driver CD which includes the BIOS, Drivers and Manual for your motherboard.**